
For Models: GB2SHDXTQ11, GB2SHDXTB11, GB2SHDXTS11, GB2SHDXTL11 (White) (Black) (Stainless Steel) (Satina) Literature Parts 11. 17. 

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# **CABINET PARTS**

Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	67006473	Screw	22		Cover, Water Valve
	W10137645		12		Cover, Water Line	23		Cover, Unit
	W10179468	Energy Guide	13	67006303	Screw (3)	24	W10137519	Elbow, Fill Tube
	W10165418	Tech Sheet	14		Hinge, Center	25		Insulation, Sound
				67006960		26	W10164397	
2		Cabinet (Not a		67007043	Black	27	67001067	
		Servicable Part)	15	67006433	Screw	28	12566604ED	<i>5 /</i> 1
3		Plug, Button (3)	16		Cover, Corner	29		Cover, Hinge
	67001130	White		67003484	White		67001014	
	67001131	Black		67003485	Black		67001012	
4	B5759649	Insulation	17		Foot, Cabinet	30	67003868	Foot Brake
5		Roller Assembly	18	67006564	Screw (8)			
6		Clip, Grille	19		Grille Assembly			
7	67006642	Pin, Center Hinge			(Includes Clips)	Fol	lowing Pa	irts Not Illustrated
8	67006611	Bolt, Adjusting		67007004	White	-		
		(Front Roller)		67006954	Black		8170942	Clamp, Tube
9	67006521	Screw	20	M0114003	Clip			
10	67006380	Screw (3)	21	67006425	Screw			

## FREEZER LINER PARTS




## FREEZER LINER PARTS

For Models: GB2SHDXTQ11, GB2SHDXTB11, GB2SHDXTS11, GB2SHDXTL11 (White) (Black) (Stainless Steel) (Satina)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A
•		Seviceable Part)
2	67001291	Gasket, Foam
2 3	12002497	Gear (Left)
-		(Includes Item 7)
4	67003905	Cover, Light
5	67004261	Shaft
6	Y12570701	Socket, Light
7	12002497	Gear(Right)
•		(Includes Item 3)
8	67006473	Screw
9	A0282812	Bulb, Light
10	67001035	Housing, Frz. Light
11	67005872	Cover, Evaporator
12	67006425	Screw
13	0.000.20	Bracket, Door
. •	W10122147	Left
	W10122148	Right
14	67003906	Housing, Lighting
15	W10167028	Clip, Evap. Motor
16	67005653	Switch, Light
17	67006530	Screw
18	0.00000	Bracket, Basket
	W10187668	Left
	W10187677	Right
19	W10120018	Slide, Drawer
20	67003731	Gasket, Bottom
21		Bracket, Slide
	W10128118	Left
	W10128119	Right
22	W10175909	Cover, Fan Shroud
23	W10167023	Shroud, Evap.Fan
24	2169142	Blade, Fan
		(Evaporator)
25	W10121318	Grommet
26	67003636	Motor, Evaporator
27	D7753903	Funnel, Drain
28	M0500703	Seal
29	B8381501	Gasket
30	12002355	Thermistor
31	67003924	Cover, Thermistor
32	67006406	Screw
Fol	lowing Pa	rts Not Illustrated


67006095 Harness, Lights (Freezer)

# FREEZER DOOR PARTS




Illus No.	. Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION	Illus.	Part No.	DESCRIPTION
1		Freezer Door	2	00=400014	Handle	4		Mount, Handle
		(w/ Insulation)		2254600W		5	67006901	
	W10187672			2254600B		6		Plug, Button (2)
	W10187673	Black		2254600S	Stainless Steel		10712401	White
	W10170543	Stainless Steel	3		Door Gasket,		67004838	Black
	W10187676	Satina			Magnetic			
				W10130894				
				W10130587	Black			

## **REFRIGERATOR LINER PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A	8		Housing, Light			
2	Y67003896	Serviceable Part) Bracket, Control	9 10		Bulb, Light (2) Socket, Light (2)	Follo	wing P	arts Not Illustrated
3	67005190	and Lights	11	67003900	Insert, Damper Cover		8208198	3 Harness, Controls
-	W10185244		12	67006602	•		0_00.0	(Refrigerator)
5	\M/10165748	Electronic Control Board, Control	13 14		Cover, Damper Insulation			(Includes # 16)
6	C3680310	Switch, Light	15	W10127429	Control, Damper			
7	67003897	Cover, Light	16   17		Thermistor Plug Button			


# **REFRIGERATOR DOOR PARTS**



# **REFRIGERATOR DOOR PARTS**

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door
		(w/Liner)
	12658565W	
	12658565B	
		Stainless Steel
_	W10187675	
2 3 4 5	67006901 67003819	
ى 1	67003619	
5	67003777	Bucket
J	07000777	(Medium)(4)
6		Plug, Handle Hole
_	67001130	
	67001131	Black
	12246606	Stainless Steel
7		Plug, Button
	10712401	
•	67004838	Black
8		Door Gasket,
	W10130893	Magnetic White
	W10130693 W10131327	
9	W10131321	Door Handle
0	2254600W	
	2254600B	
	2254600S	
10		Door Closure
	67003638	
	67003639	
11		Mount, Handle
12	67001748	
13 14	67006287	
14	67003779	Stop, Door
	67003779	
15	07000700	Bushing
10	67004977	
	67004978	
16	2220214	Nameplate

## **UNIT PARTS**



## **UNIT PARTS**


Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12	67005744 67006425 67005491 W10167036 W10119856 67004713 61004743 67001794	Blade, Fan Basepan Screw Block, Condenser Tube, Discharge Harness, Evap. Heater Drain Pan Grommet (3) Evaporator Heater Clip, Capacitor	29 30	67001084 67001083 67004432 10428101 13060302 B2150504 W10130129 2264017 67006434 W10158508 67004953 67004954	Motor, Fan Clip, Heater Harness, Unit Drier (Service) Compressor Capacitor Axle, Roller Shroud Bracket, Fan Motor		978028 978028	
13 14 15 16 17 18 19 20 21	W10137529 67006573 W10169124 67006132 67006432	Thermostat Grommet Screw Grommet Condenser Screw Tray, Drip	35 36 37		Roller Clip, Evaporator Grommet (2)	REF	876764	(5/8") Valve, Access (3/4") Valve, Access (3/16")  ANT CHARGE  5.00 Ozs. (R-134A)

## **SHELF PARTS**

## **SHELF PARTS**

Illus. No.	Part No.	DESCRIPTION
1	67001057	Rail, Center Crisper
2	67003935	
2 3	67005864	
4	67004986	Basket, Freezer (Upper)
5	67006024	
6	67006360	Screw (2)
7	67006626	
8	67006644	
9	67001314	
10	67004127	Divider, Basket (Upper)
11		Bracket, Glide
	67001053	
4.0	67001054	
12	67002373	Shelf, Sta (4)
13	67006608	
14	67002633	1 - \ /
15	67001059	,
16 17	67001056	Frame, Crisper
17	67006878 67001073	
19	67001073	Ladder, Side
20	67006400	

## **ICEMAKER PARTS**



## **ICEMAKER PARTS**

Illus No.	. Part No.	DESCRIPTION
1		Mold & Heater (Not Available, Order 4396418) Assembly
2	4344265	Clip
2 3 4	8170928	Bearing & Inlet
4 5	8170927 8170929	Ejector
6	8170932	Ice Stripper Support
7	8170930	Retainer,
		Thermostat (2)
8		Thermostat
		(Not Available,
9	8170933	Order 4396418) Screw (4)
10	67005603	Funnel, Fill Tube
11	67001255	Pan, Ice
12	67006662	Screw
13	67004028	
14 15	W10153408 8170931	Harness, Ice Maker Clip, Ice Maker
16	67004710	Cover
17	0.00	Module Assembly
		(Not Available,
40	07000750	Order 4396418)
18 19	67003753 8170943	Valve, Water Inlet Screw
20	4344402	
21	8208151	Tube, Water
22	4343984	Clip, Wire
23	4343675	Screw
100	W10122519	Complete Icemaker

### **OPTIONAL PARTS**

For Models: GB2SHDXTQ11, GB2SHDXTB11, GB2SHDXTS11, GB2SHDXTL11 (White) (Black) (Stainless Steel) (Satina)

Illus. Part
No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 72032 Black 4392901 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

\*350942 Primer, White \*350930 White \*350939 Black \*4392901 Biscuit

\*Important: The spray paint is not to be used where the paint may make contact with the door gaskets. Illus. Part
No. No. DESCRIPTION

PAINT, BULK (1 qt.)

799344 White (Uncut) 799344 Black (Uncut) 4392900 Biscuit (Uncut)

Miscellaneous

212643 Sealer, Gum (4 Feet) 479502 Tape, Vinyl (3/4 x 108") 505587 Sealer, Mastic (1 Qt.) 503695 Cork, Sealer (1/4 Pound) 542638 Grease, Silicone (1/2 Oz.) 542639 Cement, Alumilastic (1-1/4 Oz.) 799833 Kit, Evaporator Repair (Aluminum Epoxy) 833938 Kit. Terminal Connector

Illus. Part
No. No. DESCRIPTION

**TORX SCREW WRENCH** 

1117510 Torx Key

**ACCESSORIES** 

2217192 Cleaner, Stainless Steel